

FITTING THE 'F' CONNECTOR

AE3001

The coaxial cable supplied with the AE3001 will need to be terminated with the supplied 'F' connector. Before fitting the 'F' connector, first route the cable through the vehicle towards the television and trim excess cable if required.

Once the cable has been routed to the television, the free end of the cable will need to be cut as per figure '1' to accept the additional 'F' connector supplied. Once cut, insert the cable into the back of the 'F' connector and screw the connector onto the cable as far as possible. When fitted correctly the centre pin of the coax should protrude through the front of the connector as shown in figure '2'.

Use the included adaptor 'F' to PAL to attach the antenna to the digital TV.

Figure 1 - Coax Cable Cutting Measurements




Figure 2 - Fitting the 'F' Connector

